

# Sample Integrity

Really Local. Truly Global.

***"The result of any test can be no better than the sample on which it is performed".***

## **Principles of Sampling**

Sampling requires two very important processes to be completed correctly. The first is the sampling itself, and the second is the paperwork associated with each sample. We use the terms Representative and Traceable to describe the sampling process, getting both performed correctly means that our results will be as accurate as possible.

This brochure has been compiled to provide our customers with a brief overview of the techniques required for accurate sampling.

## **Representative**

"A sample must have the same distribution of characteristics as the body from which it is drawn. Only then, can the sample be used to draw conclusions about the greater body".

This means that if the sample is taken wrong then our results will be wrong.

## **Traceable**

Traceability refers to the completeness of the information about every step from the time the sample is taken until we deliver your report.

If the samples you collect get mixed up at any stage in the process then the results we deliver could be wrong.

This means you need to include accurate paperwork for each sample you submit.

## Table of Contents

Introduction	Page 4
Bottle Types and Labels	Page 5
Sampling Techniques	Page 9
Potable Water	
Environmental Surface and Receiving Waters	
Ground Waters	
Trade Waste	
Compliance Samples	
Cooling Towers and Legionella Samples	
Soil, Sludge and Solid Materials	
Interceptors and Grease Traps	
Swimming Pools	
Effluent	
Sample Preservatives, Filtration, and Delivery	Page 15
Chemicals that we add	
Filtration of samples	
Delivery Details	
Contact Us	Page 16

## Introduction

Eurofins is New Zealand's leading laboratory network in the areas of Food, Water and Environmental testing and sampling services. We have been providing these services in New Zealand for over 20 years.

Eurofins Scientific is the world leader in the fields of food testing and environmental laboratory services. It is also number one in the world in pharmaceutical products testing and one of the global market leaders in agrosience, genomics, pharmaceutical discovery, and central laboratory services.

We understand that New Zealand food companies pride themselves in producing good quality, high grade items for consumption in both the domestic and export markets. Our aim is to work with you by providing premium quality testing support services for your quality control requirements and brand protection needs.

We have strategically positioned laboratory facilities in Auckland, Taupo, Hastings, Wellington, Christchurch and Dunedin, offering a comprehensive scope of sampling and testing services whilst ensuring that samples from around New Zealand are processed into the laboratory as fast as possible.

Areas that we specialise in are as follows:

- Food and Feed Testing
- Food Safety and Auditing
- Fruit Quality Services
- Agricultural Testing
- Environment Testing
- Contaminated Land
- Agrosience Services
- Pharma Development
- Consumer Product Testing

## Who should read this brochure?

This brochure has been prepared for everybody who collects samples for laboratory analysis. Recent changes to laboratory accreditation rules mean that we now know the uncertainty associated with each analytical test. Through this process we have determined that the factor contributing most uncertainty, is sampling.




Eurofins is dedicated to providing the most accurate result possible for our clients and this process begins with assisting our clients to collect samples. This brochure explains the bottles and preservatives used, as well as some suggested sampling procedures











## Bottle Types and Labels




Eurofins delivers a range of bottle types featuring different labels to our clients based on the sampling technique and preservatives required for each analysis.

Each bottle will have a colour-coded label attached which details the hazards associated with any preservatives inside that bottle. Safe handling procedures are also explained on the label and should be followed by everybody handling the bottles.

	<p><b>Unpreserved bottle – various sizes Dark Purple Border</b> Used for all water types and effluents</p> <div data-bbox="552 696 898 902"> <p><b>Chemistry Water Sample</b> Including: pH, Alkalinity, Turbidity, BOD and solids</p> <p><b>eurofins</b></p> <p>(Unpreserved) This bottle contains no chemical preservation prior to filling. Chill samples with zero-headspace.</p> <p>Client: _____</p> <p>Ref: _____</p> <p>Sample ID: _____</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p><input type="checkbox"/> Filtered <input type="checkbox"/> Not Filtered</p> <p>Auckland: 09 579 2669    Wellington: 04 576 5016    Christchurch: 03 343 5227</p> </div> <p>This bottle is used for 'shorts', such as BOD, suspended solids, pH, conductivity, turbidity, and alkalinity species.</p>
	<p><b>Sterile bottle – various sizes, Black Border</b> Used for all water types effluents, and solids</p> <div data-bbox="552 999 898 1205"> <p><b>Microbiology (Unpreserved)</b> <b>eurofins</b></p> <p>(Unpreserved) This bottle contains no chemical preservation prior to filling. Chill samples with a small headspace.</p> <p>Client: _____</p> <p>Ref: _____</p> <p>Sample ID: _____</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p><input type="checkbox"/> Filtered <input type="checkbox"/> Not Filtered</p> <p>Auckland: 09 579 2669    Wellington: 04 576 5016    Christchurch: 03 343 5227</p> </div> <p>Can be used for all microbiological analyses such as E.coli or Enterococci.</p> <div data-bbox="552 1227 898 1433"> <p><b>Microbiology (Preserved)</b> <b>eurofins</b></p> <p>Preserved with Sodium thiosulphate. Chill samples with a small headspace.</p> <p>Client: _____</p> <p>Ref: _____</p> <p>Sample ID: _____</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p><input type="checkbox"/> Filtered <input type="checkbox"/> Not Filtered</p> <p>Auckland: 09 579 2669    Wellington: 04 576 5016    Christchurch: 03 343 5227</p> </div> <p>The preserved bottle contains sodium thiosulphate for potable water samples.</p>
	<p><b>60ml Dissolved Nutrients Tube – Yellow Border</b> Used for all water types and effluents</p> <div data-bbox="552 1559 898 1765"> <p><b>Dissolved Nutrients</b> Including: DRP, Ammonia, NNN</p> <p><b>eurofins</b></p> <p>(Unpreserved) This bottle contains no chemical preservation prior to filling. Chill samples with zero-headspace.</p> <p>Client: _____</p> <p>Ref: _____</p> <p>Sample ID: _____</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p><input type="checkbox"/> Filtered <input type="checkbox"/> Not Filtered</p> <p>Auckland: 09 579 2669    Wellington: 04 576 5016    Christchurch: 03 343 5227</p> </div> <p>Use this bottle for dissolved nutrients such as DRP, Nitrate-Nitrite Nitrogen, and ammonia. It is recommended that the sample be filtered on-site, the bottle filled to the shoulder, then frozen.</p>

	<p><b>60mL Anions Tube – Aqua Border</b> Used for all water types and effluents</p> <div data-bbox="560 360 906 573"> <p><b>Anions</b> Including: Fluoride, Chloride, Sulphate, Nitrate and Nitrite</p> <p><b>eurofins</b></p> <p>Client: _____ (Unpreserved)  Ref: _____ This bottle contains no chemical preservation prior to filling. Chill samples with zero-headspace.  Sample ID: _____ 537/28 – Wear suitable gloves and eye/face protection.  Date/Time: _____  Sampled By: _____</p> <p>Auckland: 09 579 2689 Wellington: 04 578 5016 Christchurch: 03 343 5227</p> </div> <p>Sulphate, Fluoride, Chloride, and other anions are collected in this bottle. It is recommended that the sample be filtered on-site wherever possible.</p>
	<p><b>50mL Tube– Silver Border</b> Used for all water types and effluents</p> <div data-bbox="560 707 906 920"> <p><b>Metals</b></p> <p><b>eurofins</b></p> <p>Preserved with traces of Corrosive Nitric Acid (50N201). This bottle contains 0.5% by volume of 50N Nitric Acid, which prior to filling, may prove hazardous. Once filled, the Nitric Acid strength is 0.1% v/v solution.</p> <p>528 – Very corrosive.  537/28 – Wear suitable gloves and eye/face protection.  528 – In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.  528 – After contact with skin, wash immediately with plenty of water.  Total – Dissolved (field filtered at 0.45 microns) Or leave to settle as 'as received' (clean water only).</p> <p>Client: _____  Ref: _____  Sample ID: _____  Date/Time: _____  Sampled By: _____</p> <p>Auckland: 09 579 2689 Wellington: 04 578 5016 Christchurch: 03 343 5227</p> </div> <p>This bottle is for the collection of metals samples and contains nitric acid which prior to filling may prove hazardous. It should not be overfilled.</p> <div data-bbox="560 954 906 1167"> <p><b>Dissolved Metals</b></p> <p><b>eurofins</b></p> <p>(Unpreserved)  This bottle contains no chemical preservation prior to filling. Chill samples with zero-headspace.  537/28 – Wear suitable gloves and eye/face protection.</p> <p><input type="checkbox"/> Filtered  <input type="checkbox"/> Not Filtered</p> <p>Client: _____  Ref: _____  Sample ID: _____  Date/Time: _____  Sampled By: _____</p> <p>Auckland: 09 579 2689 Wellington: 04 578 5016 Christchurch: 03 343 5227</p> </div> <p>This bottle is also used to collect dissolved metals. It is recommended to field filter these samples prior to delivery to the lab.</p>
	<p><b>60mL Total Nutrients bottle – Red Border</b> Used for all water types and effluents</p> <div data-bbox="560 1279 906 1491"> <p><b>Total Nutrients</b> Including Nitrogen and Phosphorus</p> <p><b>eurofins</b></p> <p>(Unpreserved)  This bottle contains no chemical preservation prior to filling. Chill samples with zero-headspace.  537/28 – Wear suitable gloves and eye/face protection.</p> <p>Client: _____  Ref: _____  Sample ID: _____  Date/Time: _____  Sampled By: _____</p> <p>Auckland: 09 579 2689 Wellington: 04 578 5016 Christchurch: 03 343 5227</p> </div> <p>Total Phosphorus and Total Nitrogen are sampled in this bottle. It is recommended that the bottle be filled <u>almost</u> to the top, frozen (or chilled) then delivered to the lab</p>
	<p><b>1L Glass Oil and Grease – Light Blue Border</b> Used for effluent, trade waste</p> <div data-bbox="560 1682 906 1895"> <p><b>Oil and Grease</b></p> <p><b>eurofins</b></p> <p>Preserved with traces of Corrosive Hydrochloric Acid (50N788). This bottle contains 0.5% by volume of 50N hydrochloric acid which prior to filling may prove hazardous. Once filled the Hydrochloric Acid strength is 0.1% v/v.</p> <p>528 – Very corrosive.  537/28 – Wear suitable gloves and eye/face protection.  528 – In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.  528 – After contact with skin, wash immediately with plenty of water.</p> <p>Client: _____  Ref: _____  Sample ID: _____  Date/Time: _____  Sampled By: _____</p> <p>Auckland: 09 579 2689 Wellington: 04 578 5016 Christchurch: 03 343 5227</p> </div> <p>This bottle is used for oil and grease samples and contains hydrochloric acid which, prior to filling may prove hazardous. Please fill to the line indicated.</p>

	<p><b>250mL Brown Glass Bottle – Light Brown Border</b> Used for all water types</p> <div data-bbox="555 349 906 562"> <p><b>Organic Carbon Analysis</b> Including TOC and NPOC</p> <p><b>eurofins</b></p> <p>Client: _____ (Unpreserved) This bottle contains no chemical preservation prior to filling. Only samples with zero headspace.</p> <p>Ref: _____</p> <p>Sample ID: _____ <b>S37/29</b> – Wear suitable gloves and eye/face protection.</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p> </div> <p>Used for all forms of carbon analyses including Total Organic Carbon, Dissolved Organic Carbon, Non-Purgeable Organic Carbon, and Purgeable Organic Carbon. Please fill the bottle carefully so that air is not introduced. Refrigerate before delivery.</p>
	<p><b>250mL Glass Mercury – Dark Blue Border</b> Used for all water types and effluents</p> <div data-bbox="555 763 906 976"> <p><b>Mercury</b></p> <p><b>eurofins</b></p> <p>Preserved with traces of Corrosive Nitric Acid (UN2831). This bottle contains 1% by volume of 50% Nitric Acid, which prior to filling may prove hazardous. Once filled, the Nitric Acid strength &lt;0.15% aq. solution.</p> <p><b>S26</b> – Very corrosive.</p> <p><b>S37/29</b> – Wear suitable gloves and eye/face protection.</p> <p><b>S26</b> – In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.</p> <p><b>S28</b> – After contact with skin, wash immediately with plenty of water.</p> <p>Client: _____</p> <p>Ref: _____</p> <p>Sample ID: _____</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p> </div> <p>This specially cleaned and preserved bottle is used specifically for the collection of mercury samples. It contains nitric acid which prior to filling may prove hazardous and should be filled without overflowing. Once sampled it does not require refrigeration.</p>
	<p><b>60mL COD bottle – Light Orange Border</b> Used for non-potable waters effluents</p> <div data-bbox="555 1200 906 1413"> <p><b>Chemical Oxygen Demand</b></p> <p><b>eurofins</b></p> <p>Preserved with traces of Corrosive Sulphuric Acid (UN2796). This bottle contains 0.5% by volume of 50% Sulphuric Acid, which prior to filling may prove hazardous. Once filled, the Sulphuric Acid strength &lt;0.15% aq. solution.</p> <p><b>S26</b> – Very corrosive.</p> <p><b>S37/29</b> – Wear suitable gloves and eye/face protection.</p> <p><b>S26</b> – In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.</p> <p><b>S28</b> – After contact with skin, wash immediately with plenty of water.</p> <p>Client: _____</p> <p>Ref: _____</p> <p>Sample ID: _____</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p> </div> <p>This bottle contains sulphuric acid which prior to filling may prove hazardous. The bottle should be filled without overflowing.</p>
	<p><b>60mL TKN bottle – Dark Orange Border</b> Used for non-potable waters effluents</p> <div data-bbox="555 1603 906 1816"> <p><b>Total Kjeldahl Nitrogen</b></p> <p><b>eurofins</b></p> <p>Preserved with traces of Corrosive Sulphuric Acid (UN2796). This bottle contains 0.5% by volume of 50% Sulphuric Acid, which prior to filling may prove hazardous. Once filled, the Sulphuric Acid strength &lt;0.15% aq. solution.</p> <p><b>S26</b> – Very corrosive.</p> <p><b>S37/29</b> – Wear suitable gloves and eye/face protection.</p> <p><b>S26</b> – In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.</p> <p><b>S28</b> – After contact with skin, wash immediately with plenty of water.</p> <p>Client: _____</p> <p>Ref: _____</p> <p>Sample ID: _____</p> <p>Date/Time: _____</p> <p>Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p> </div> <p>This bottle contains sulphuric acid which prior to filling may prove hazardous. The bottle should be filled without overflowing.</p>

	<p><b>250mL Brown Glass Organics Bottle – Dark Brown Border</b></p> <p>Used for all water types This bottle can be used for a wide range of organic chemistry parameters such as TPH, Acrylamide and Taste and Odour Compounds.</p> <p>It does not contain preservative.</p>
	<p><b>250mL Brown Glass VOC Bottle – Light Purple Border</b></p> <p>Used for all water types</p> <p>This bottle is used to collect Volatile Organic Compounds including BTEX and contains sodium thiosulphate as a preservative.</p> <p>Please fill the bottle so that there is no headspace, then chill and send to the lab.</p>
	<p><b>250mL Brown Glass SVOC Bottle – Light Blue Border</b></p> <p>Used for all water types</p> <p>This bottle is used to collect Semi-Volatile Organic Compounds including PAH and pesticide residues and contains sodium thiosulphate as a preservative.</p> <p>Please fill the bottle so that there is no headspace, then chill and send to the lab.</p>

### Other Labels you may see:

<p><b>Sulphite</b> Contains EDTA</p> <p>Client: _____ Ref: _____ Sample ID: _____ Date/Time: _____ Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p>	<p><b>Sulphide</b> Contains Zinc Acetate and Sodium Hydroxide</p> <p>Client: _____ Ref: _____ Sample ID: _____ Date/Time: _____ Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p>
<p><b>Oxyhalide</b> Including: Bromate, Chlorate and Chlorite</p> <p>Client: _____ Ref: _____ Sample ID: _____ Date/Time: _____ Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p>	<p><b>Cyanide</b></p> <p>Client: _____ Ref: _____ Sample ID: _____ Date/Time: _____ Sampled By: _____</p> <p>Auckland: 09 579 2669 Wellington: 04 576 5016 Christchurch: 03 343 5227</p>



## Sampling Techniques

### Sampling

The objective of sampling is to collect a portion of material small enough in volume to be transported conveniently and handled in the laboratory while still accurately representing the material being sampled.

Sampling is an often underestimated but very crucial step in the analytical process. Many things can go wrong before the sample reaches a laboratory, so we offer assistance to minimise risk associated with:

- Inappropriate sample types and locations
- Incorrect sampling technique
- Sample contamination
- Incorrect labelling
- Sample homogeneity
- Delivery timeframes

The bottles detailed above can be used to collect any type of sample, however the collection of samples is varied. The details below are designed to assist samplers in the collection of these sample types.

It is important to take care when filling sample bottles. Never rinse out sample bottles or use a sample bottle that has preservative to fill another bottle. Some sample bottles contain a preservative - as stated on the bottle. These bottles should not be over-filled and special care taken not to touch the opening of the bottle or the inside of the lid. Bottles containing preservative are usually smaller and are for specialist analyses. Bottles that do not contain preservative are usually larger and can be filled to overflowing.

### **Collecting Potable Water Samples – Ask us for a copy of our procedure**

Wherever possible a tap must be cleaned, sterilised, and then flushed for at least two minutes or for as long as it takes to flush stagnant water from the pipe. After flushing please fill the bottles without overflowing, as many contain special preservatives that must stay in the sample.

#### For bacterial analysis

Select a clean tap that is free from contamination and is supplying water directly from the main. Open tap fully to flush out the stagnant water. Reduce flow to permit filling bottle without splashing, do not overflow.

- Use a dedicated cold-water tap.
- Take care when opening and closing the bottle and make sure that no contamination enters bottle. Don't touch the rim of the bottle with your fingers or any other object.
- Make a note of the time and date of sampling on the bottle label and store the bottle in the fridge until delivery to the laboratory.

The sample must be analysed by Eurofins within 24 hours of sampling to ensure accurate test results. We require that potable water samples be delivered at below 10°C so the samples may need to be in a chilly bin along with some ice packs.

#### For chemistry analysis

Collect any chemistry samples after the microbiological sample to avoid contamination. Samples should be collected in the appropriate bottles for each test following the instructions on the label. If you are only collecting a chemistry sample, then there is no need to sterilise the tap.

If pre and post flush samples are required for plumbosolvency testing, then fill a metals tube before flushing any water through the tap. This sample is the pre-flush. Follow the standard procedure for the post-flush sample.

NOTE: We are legally obligated to notify the DHB of any test results that exceed published Maximum Allowable Limit.

#### **Environmental and Receiving Waters**

Many water bodies (rivers, streams, ditches etc) are shallow and well mixed and surface (0-1m) water sampling is all that is required. For this purpose, immersion of a sample bottle by hand to just below the surface (typically 0.25-0.5m) is satisfactory. Ideally the sampler should be wearing a plastic disposable glove and be standing downstream of where the sample is being collected. Always sample upstream of any other action in the water that may result in stirring up sediment (eg. ducks, cows crossing or drinking, other monitoring work). If the sample is being collected from a boat (eg. lakes, wetlands, ocean waters), the boat should be facing into the ongoing current and the sample collected from the front of the boat. This minimises contamination from the boat itself. To keep some distance between the sampling point and the boat it is acceptable to use a bucket attached to a rope to obtain the sample to fill the bottle. The bucket should be cleaned before use and stored appropriately between uses.

#### Algae Sampling

Algae are sampled into bottles containing iodine as a preservative.

- When sampling rivers or streams collect samples from flowing water upstream from where you are standing. Sample by holding a bottle facing upstream and then tipping the contents into the iodine preserved bottle. Do not spill the iodine from the sample bottle.
- When sampling ponds or still water the most algae will be found in the top 30cm of the water column. Sampling by scooping a bottle through the water and then tipping the contents into the iodine preserved bottle. Do not spill the iodine from the sample bottle.
- Put the bottles into a chilly bin containing ice for delivery to the lab.

### **Ground Water Samples**

Groundwater occurs in aquifers at various depths below the ground. Recharge may be by direct infiltration of rainfall, by seepage from rivers or other bodies of surface water, or by transfer from one aquifer to another. The area of recharge may be at the sampling site or many hundreds of kilometres away. The water may have been in the aquifer for days or millions of years.

The quality of groundwater can vary from almost pure to extremely concentrated brines. Its quality depends on the geology of the aquifer and can be subject to contamination from substances that come into contact with the ground. Fertilisers, pesticides, petroleum products, landfills, mining, household and farm and industrial wastes all contaminate groundwaters to varying degrees, often much more than surface waters.

Monitoring of the quality of groundwaters involves techniques different from those used for surface water quality investigations because groundwater, by its very nature, cannot be sampled without some disturbance from the construction of a bore or other access hole and the effects of sampling devices and procedures.

Sampling staff must take extreme care to ensure that samples are representative of the water in the aquifer. To retrieve a representative sample the following principles should be considered:

- The sampling equipment should not change the water quality in any way and particular effort should be made to avoid cross-contamination between bores and sampling equipment.
- Sufficient water should be removed to ensure the sample is newly derived from the aquifer itself rather than from water that has sat in the bore.

The aim of sampling water from a well is to obtain a sample representative of the water in the aquifer outside the well. All wells should be purged for a period of time before sampling to flush out non-representative water from the well and any connected pumping system. Stagnant water in the well may give results unrepresentative of conditions in the aquifer, because physical parameters such as temperature and contact with well construction materials may differ from those conditions in the aquifer. These physical differences are likely to cause changes in the chemical composition of the water standing in the well. Also note that some parameters will unavoidably change through contact with air. Iron is particularly affected, and often a clear sample can turn brown within a few minutes.

A commonly used guide for determining the amount of water that should be purged from a well is that at least 3 times the volume of water sitting in the well casing must be flushed from the system. This volume is known as the 'standing volume' which can be calculated as:  $\pi \times r^2 \times \text{depth} \times 3$  where  $\pi$  is equal to 3.142,  $r$  is the radius of the well head (equal to half the diameter) and depth is the total well depth minus the depth of water level (established using a dip-probe).

### **Trade Waste**

Trade Wastes can contain particularly toxic and dangerous compounds, so it is important that Health and Safety procedures are followed at all times.

Eurofins has identified the sampling technique as the major contributor to inaccuracy in expected results, so we have developed several sampling techniques that minimises the risk associated with this part of the process.

- Three grab samples of the discharge shall be taken at intervals of not less than 1 minute or more than 5 minutes. These are combined using equal volumes of all three samples to obtain an instantaneous sample.
- A four-hour average sample is prepared by taking not less than 12 grab samples over a continuous four-hour period. The intervals between the samples must not be less than 5 minutes nor more than 30 minutes. The samples shall be mixed using equal volumes of all samples to obtain the four-hour average sample.
- A twenty-four hour flow proportionate sample is obtained from no less than 18 grab samples over a continuous twenty-four hour period.

We recommend a combination of manual and autosampler techniques to collect representative samples in order to meet client and council specifications. Our specialist operators are able to achieve such tasks as pre-programming the autosamplers to collect samples on a particular day on a time or flow basis.

### **Compliance Samples**

Samples that are collected for the purpose of compliance against environmental standards usually require rigorous attention to the details contained in this brochure. Correct bottles and a chain of custody should be used at all times.

A typical compliance sample kit may consist of the following:

- Unpreserved Bottle for pH and suspended solids
- COD/TKN bottle for either or both of these tests
- Sterile bottle to check for microbial contamination
- Total Nutrients bottle to check for phosphorus and nitrogen contamination

The types of samples you will be most likely to collect will include grab samples or samples collected by automatic sampler. If you require samples to be collected over an extended time frame, please consider an on-site automatic sampler. Further details are shown in the Trade Waste section on page 10. Eurofins can advise you what tests are best to achieve the desired outcome, however if you know the tests you require please refer to the bottle type section to determine which bottle should be used for that test.



## **Cooling Towers and other Legionella Samples**

### Safety Precautions

A facemask and other protective clothing as required are to be worn when collecting water samples from cooling towers. The condition of the tower should be recorded to include the presence of biological growths and sludge.

### Sample Collection from Cooling Towers

- Obtain water samples from incoming supply to tower from the header tank or the ball valve in the tower.
- Collect samples in 100mL sterile containers from pond water furthest away from the make-up and from the water return line of the circulation system to the tower. If this is not practical, take samples from cooling tower pond. Sludge and biofilm material can also be analysed.
- Samples that cannot be processed immediately should be kept in a refrigerator for not more than 24 hours.

### Collection of Samples from Water Services within Buildings

- Collect samples from cisterns, calorifiers, hot water cylinders, and showers in 100mL sterile containers. Samples should be collected before and after outlets are flushed and from the distal point of each service.
- The external surface and rim of the outlet being sampled should be clean and free of deposits.

### Samples from Shower Heads, etc.

- Remove showerhead etc from the fixture and allow water to drip out.
- Moisten a sterile swab with water and thoroughly swab the inside of the pipe, showerhead etc.
- Break the swab aseptically into a 100mL sterile bottle containing not more than 10mL of water.
- If you wish to measure the effect of your treatment, then collect before and after samples from each source.


Samples from chlorinated sources must be free of chlorine, achieved by adding sodium thiosulphate to the container.

## **Soil, Sludge, and Solid Materials**

Due to its non-homogenous nature, solid material can be very difficult to sample. It is recommended that many sub-samples be collected from the sample site using a grid pattern, then combined into one sample for delivery to the laboratory. Most solid samples can be delivered to the laboratory inside a strong plastic bag.

### Interceptors and Grease Traps

The sample point for multi-stage interceptor will always be the last chamber where the outlet flows from. Samples should be collected from mid-depth to avoid collecting any sediment or floating material.



Grease traps should always be sampled from the outlet.

### Swimming Pools

Where possible, collect samples in the area of, and during the time of maximum bather density. Bather numbers are also noted to assist in subsequent interpretation of laboratory results.

#### Microbiology Samples

Carefully remove the bottle lid and hold bottle near its base. At a pool depth of about a metre swiftly sweep bottle through water 20cm below the surface. Make sure that the dechlorinating agent is not washed out and leave a mixing gap.

#### Chemistry Samples

Please fill an unpreserved bottle by swiftly sweeping the bottle through water 20cm below the surface.

### Effluent

Treated effluent requires testing to ensure compliance with Consent criteria. Many different consent conditions exist within New Zealand, and Eurofins has become proficient at working with many of them. Most require the following sampling techniques:

#### 24-hour composite samples

A 24-hour composite sample should be collected for all chemistry analyses so that each day is analysed discreetly. Results from each day can then be used for reporting continuous monitoring criteria.

The autosampler should be set to collect samples at sensible intervals to ensure sufficient volume is collected to represent the daily flow. Planning is required so that any heavy rainfall event is sampled without overflowing the collection vessel.

#### Grab Samples

Grab samples are useful to record a snapshot of the effluent quality and can be used when an unusual event occurs at the plant. All microbiological samples should be collected as grab samples because conditions in the autosampler are not appropriate for this test-type.

## Sample Preservatives, Filtration, and Delivery

### **Sample Preservatives**

Eurofins uses various preservation techniques to ensure the integrity of the test. Where acids are used the sampler must take precautions to avoid injury to hands and eyes. Bottle labels clearly indicate the potential hazards that may be caused by the preservatives used.

### **Filtration of samples**

Where long transit times will be encountered on-site filtration is strongly recommended for all nutrient, anion, and metals samples. Eurofins recommends the use of large syringes of 50-100mL capacity and 0.45 micron cellulose filters. We regularly perform validations on our filters of choice and will recommend only those filters that pass our criteria. Eurofins is, however, happy to filter the samples when they are received as long as our client recognises the implications.

### Anions and Metals

A high turbidity level in samples is not desirable for anion and metals determinations. Any sample that is turbid ( $>1$  NTU) must be filtered through a  $0.45\mu\text{m}$  cellulose filter prior to analysis, and preferably on-site during the sampling process. Samples of 1 NTU appear cloudy to the naked eye, so if a sample appears clear then it does not require filtration.

Removal of particulate by filtration is further recommended on-site so that it cannot dissolve in transit leading to elevated results.

### Nutrients

All Dissolved Reactive Phosphorus, NNN, and low-level ammonia samples require filtration.

### **Delivery to the Lab**

In order to assure the samples are delivered in the appropriate manner, Eurofins recommends the following procedure is followed wherever possible. If these procedures cannot be met, then the test may not IANZ endorsed.

All samples should be delivered to the laboratory as soon as possible and within 24 hours. Microbiological activity continues even at  $10^{\circ}\text{C}$  so the sooner we receive samples the better. We use pilot samples as a delivery temperature check. Please ask us for instructions.

A chain of custody should be included with all deliveries so that we can check the sampling time and sample details. Sample receipt is acknowledged, and the details included on the Chain of Custody will be used to prepare your report. Please make sure your Chain of Custody is as complete as possible to avoid confusion.

Eurofins accepts samples from Monday to Saturday. If you send samples on a Friday, you will require a Saturday delivery sticker.

## Contact

**Telephone:** 0800 387 63467

**Email:** [infonz@eurofins.com](mailto:infonz@eurofins.com)

**Web:** [www.eurofins.co.nz](http://www.eurofins.co.nz)

## Courier

### **Auckland**

35 O'Rorke Road, Penrose, Auckland 1061

### **Taupo**

150 Rickit Street, Taupo 3330

### **Wellington**

85 Port Road, Seaview, Lower Hutt 5010

### **Hamilton**

12-14 Pukete Road, Te Rapa, Hamilton 3240

### **Hastings**

1139 Maraekakaho Road, Longlands, Hastings 4175

### **Christchurch**

43 Detroit Drive, Rolleston 7675

### **Dunedin**

16 Lorne Street, South Dunedin 9012

