

## **Asbestos**

### **Transmission Electron Microscopy (TEM) Sample Analysis**

AHERA

ISO 10312

Asbestos in Drinking Water

Asbestos in Waste Water

PCM Equivalent

Qualitative – Presence/Absence (Air or Bulk)

Microvac (Dust or Bulk)

Semi-Quantitative - Chatfield

### **Phase Contrast Microscopy (PCM) AIR Sample Analysis**

### **Polarized Light Microscopy (PLM) BULK Sample Analysis**

Point count

## **Chemistry**

### **Atomic Absorption Spectroscopy (AAS) or Inductively Coupled Plasma (ICP)**

### **Air, Bulk, Dust, Paint, Soil, Wipe, and Water Analysis**

Aluminum

Antimony

Arsenic

Barium

Beryllium

Cadmium

Cobalt

Chromium

Copper

Iron

Lead

Magnesium

Molybdenum

Mercury

Nickel

Selenium

Silver

Strontium

Tin

Titanium

Thallium

Vanadium

Zinc.

### **RCRA 8 Metals**

### **TCLP - Single Element**

### **TCLP - RCRA 8 Metals**

### **Welding Fume Scan (15 metals)**

### **Metals Scan (23 metals)**

### **Dust – Respirable/Total**

### **Total Dissolved Solids & Total Suspended Solids**

### **Methamphetamine - Alcohol Wipe**

## Microbiology

*Salmonella*

*Listeria*

*E. coli* O157:H7

*E. coli*

Total Coliforms

*Staphylococcus aureus*

Yeast & Mold

Aerobic Plate Count (APC)

## Mold


Spore Trap Analysis

Tape Lift Identification

Mold Growth and Identification (Genus Level)

Plate Count (no identification)

Swab Analysis



## Laboratory Hours of Operation

Asbestos Laboratory

Monday - Friday 7am - 7pm Saturday  
8am - 5am

Chemistry Laboratory

Monday - Friday 8am - 5pm

Microbiology & Mold Laboratory

Monday - Friday 8am - 5pm